



PANDROL


INTEGRAL UNIT HYDRAULIC RAIL WELD SHEARING MACHINE

EME1 TYPE

REF. 11334010

OPERATING AND MAINTENANCE MANUAL

REF. 42111006



PANDROL

Siège Social et Usine : Z.I. du Bas Pré – B.P. 9 – 59590 RAISMES – FRANCE - Tél. : 33 (0) 3.27.22.26.26 - Fax : 33 (0) 3.27.22.26.00

Direction Générale et Commerciale Immeuble West Plaza – 9 rue du Débarcadère- CS90029 – 92707 COLOMBES Cedex

Tel 33.1.46.88.17.00 – Infos.pandrol@pandrol.com – Fax 33.1.46.88.17.00 et 17 66

16 of 42

En cas de litige, la version française fait référence – The French version will be decisive in cases of litigation

SUMMARY

	<u>Pages</u>
I SAFETY LABELS EXPLANATION	18
II SAFETY GENERAL INSTRUCTIONS	18
III DESCRIPTION	19
IV USE INSTRUCTIONS	19
1 – Storing	
2 – Handling	
3 – Pre-operating check	
4 – Engine positioning	
5 – Blades positioning	
6 – Pre-operating adjustments	
6.1 Blades	
6.2 Stop pieces	
6.3 Locking system	
7 - Operating	
7.1 Mould release	
7.2 Cutting	
8 – Work place	
9 – Maintenance	
V SIGNALISATION	27
VI BLADES	27
VII TECHNICAL CHARACTERISTICS	29
VIII SPARE PARTS LIST	30
- Shearing unit	
- Back crosspiece	
- Hydraulic fitting	
IX PLAN CONTROLE SUIVANT EN13977	36
X CONTROL CARDS	37
XI CE CONFORMITY CERTIFICATE	41

I – SAFETY LABELS EXPLANATION



WARNING ! The machine can be dangerous.



Careless and incorrect use results in injury to the operator



Read carefully the instructions of the operating manual
before using the machine.

II – GENERAL SAFETY INSTRUCTIONS

- Never use the shearing machine until you have read and understood the directions for use.
- Ensure compatibility of the power supply for battery charging
- Ensure that the batteries are transported separately from the engine
- The operator must ensure that no one can affect his work area (people, animals, flammable material).
- The shearing machine is specially designed to cut the metal excess after an aluminothermic weld, **don't divert of its primary function.**
- The operator must respect the regulations, procedures and particular orders of the Railway operating Network
- Never use the shearing machine when you are tired or under influence of medicines, alcohol or substances which can alter your sight, dexterity or appreciation capacity.
- All maintenance operations must be achieved by qualified staff.
- Hydraulic pipes and couplings must be correctly inspected before every use. Any defective component must be rejected.
- Shearing machine weight is rather high, so three persons are necessary to handle and place it on track under no circumstances the original design and configuration of the shearing machine should be modify.
- Make sure that the power supply is compatible for charging the batterie
- In case of rain it is possible to use the machine under the PANDROL welding protection tent. Be careful, however, not to expose the machine to water before and after being put under cover in the tent.
- Ensure that the batteries must be transported separately from the engine
- Protect the batteries from moisture!
- Do not use defective or deformed batteries!
- Do not expose the battery packs to fire!
- A defective Li-Ion battery pack can cause leakage of slightly acidic and flammable liquid!
- The engine can be dismantling from the shearing unit, **never use it for any other operation.**



II – DESCRIPTION

- The shearing machine has been designed to cut the metal excess resulting after an aluminothermic weld, this operation is carried out after mould release. The shearing machine is intended for Vignole and double head rails.
- The engine is fed with 220v monophase – 560 Hz current
- For safety instructions, environmental protection and the use of batteries, refer to the manufacturer's manual
- The machine is fitted with two hydraulic jacks, supplied at the same time and able to produce a force of 21 metric Tons under a pressure of 250 bars.
- Two hydraulically operated blades (see chapter V), on either side of the weld, move and cut off the metal excess.
- A hydraulic distributor with manual control lever allows the blades moving. Loosen the action on the distributor control lever stops the translator movement.
- With adjusting screws the blades cutting edge is exactly adjusted laterally and vertically.
- Retractable locking systems, fixed under the rail head, prevent the shearing machine from rising up and so adjust the cutting operation to the thickness of the deadhead.
-

III – USE INSTRUCTIONS

1 – Storing

The shearing machine does not require any particular conditions of storing
However attend to


- protect the jack's columns from shocks
- avoid inclining the shearing unit, this can result in an oil leakage from the tank plug
- Store the shearing machine and its motor in a dry place

OIL RECOMMENDATION:

**HVC 32 hydraulic fluid category ISO-L-HV
ISO 11158 category HV**

2 – Handling

- 60 Kg is the weight of a shearing machine with blades in order to work
- Three persons are necessary for its handling : two on jacks' side, the third on the opposite side.



3 – Pre-operating check

- Verify the good position of the electricity supply cable so as to avoid any risk of contact with the weld or risk of cutting
- To obtain high performances and get most satisfaction with the shearing machine, realise the different recommended adjustments with a particular attention before starting the cutting operation

4 – Positioning the engine



The shearing machine and the engine are delivered in a “compact position” and this necessitate to position the engine in “use” position

Operating mode:

- Loosen the hose clamp with a n°13 flat spanner
- Turn back the motor by about 1 cm
- Orient the motor according to the desired position

5 - Blades positioning

- 1 - Take off the four screws (item **A**) maintaining the blades on the crosspieces
- 2 - Position the blades on the pins (item **G**)
- 3 - Put on and tighten the bolts with two wrenches of 22



NOTE : To select the appropriated blades, see the profile blades list page 21

6 - Pre-operating adjustments


6.1 Blades adjustments

A. longitudinal guiding

The cutting unit is guided longitudinally along the rail by 4 guiding screws (items **D** and **E**), 2 on the front crosspiece and two on the back one, which create a space between the blade cutting edge and the rail head profile.

Operating instructions

Unlock the locking nuts and unscrew the screws items **D** and **E**.
 On the left side, adjust the screw item **D** so as to obtain a space of 1,5 mm between the blade vertical cutting edge and the rail.
 On the right side, tighten the screw (item **E**) until you obtain a space of 0,5 to 1 mm between his screw end and the rail.
 Lock up the locking nuts



b. Vertical adjustment

The front and back crosspieces are each fitted with a screw item **C**

These screws must be adjusted so as to create a space of 1,5 to 2 mm between the blades cutting edge and the rail running surface.


Operating instructions

- Loosen the lock nuts and unscrew the 2 screws item **C**
- Place the 1,5 mm wedge **reference 31910308** on the rail running surface
- Place the cutting unit on the wedge
- Tighten the screws item C until the contact with the rail
- Lock up the lock nuts

To optimise the cutting, this adjustment should be realised systematically every time the blades have been sharpened or replaced.

6.2 Stop pieces adjustment

To prevent the blades cutting edges from damaging, it's absolutely necessary to leave a space of 1 mm during the two screws item **F** adjustment, these screws act like stop pieces on the travelling crosspiece.



6.3 Locking system adjustment


The locking system improves the cutting action, providing safe and quality in cutting operation.

Cutting unit placed on the rail, blades adjusted. So as to engage the locking system under the rail head, rotate its lever through 90°, then :

Operating instructions

- 1 -Turn the 2 nuts (item **G** and **H**) until the hook make contact under the rail head
- 2 -Loosen 1/8 of a turn the nut (item **H**) to create a little space
- 3 – Lock in that position by tightening the nut (item **G**)

Proceed in the same way for the 3 other locking systems



7 – Operating

Before operating the shearing machine, verify that all the adjustments described in preceding paragraph have been made. No Load Test will be performed.

7.1 Mould release


When welding operation is finished, proceed as follows :

Break the mould respecting the time required between casting and mould release according to the welding process

Push back the risers

Remove the sand from each side of the deadhead

Using a wire brush remove, on both sides of the deadhead, sand and mould debris




These operations must be done **quickly**, otherwise the deadhead may cool down too much and become impossible to cut.

7.2 Cutting

- The welder and his assistant place the shearing machine on the rail with deadhead centred in relation to the blades.
- Pivot the 4 hooks of the locking systems under the rail head.


The operator, on the hydraulic distributor side, operate the METABO motor and then maneuver the lever of the distributor, towards the weld to cut (towards himself for the return). Once the stop screws make contact with the travelling crosspiece, **immediately** reverse the lever on the distributor in order to prevent the blades from a prolonged heating



- Release the locking system hooks.


Remove the shearing machine from the rail.

- Using a hammer, break the layer that still links up the deadhead to the rail.




8 – WORK PLACE

The user's area at his workstation is represented by a white perimeter and 4 arrows



The shearing machine must always be positioned so that the user can easily handle the Internal distributor



9 - MAINTENANCE

- Take care of the cleanliness of the shearing unit so as to make a good visual inspection
- Keep a watch on columns and scraper seals aspect, immediately replace grooved columns or faulty scraper seals. This operation must be realised by qualified staff
- Keep a watch on locking systems wear, due to the friction under le rail head hooks wear out : remove and replace them when the points dimension is inferior to 8 mm

Operating instructions


1 – Push out the pin **A** and take off the handle **P**

2 – Take off the nut **G**

3 – The hook falls

To assemble new hooks, reverse order of removal

If the mechanical coupling motor – hydraulic pump present of wear signs or in



Réf produit : 31230028



OBJECT	Operation's nature	PERIODICITY		Presence of wear signs or incorrect functionning
		Before using	After using	
Complete machine	Inspection of the machine	X		
Complete machine	Clear the engine using a towel or comprimed air gun to remove the dirtness		X	
Wiper seal	Replacement		X	X
Cylinder rod	Replacement		X	X
Locking hook	Replacement		X	X
Carbon Brush	Replacement		X	X


These recommendations are not restrictive. Continuous shearing machine and well-organized preventive maintenance will extend the life of the machine.

Responsibility for maintenance is the responsibility of the owner of the equipment.
Maintenance must be carried out at least once a year by a competent and qualified person

V-SIGNALISATION

The hydraulic shearing machine benefits of traçability on the ID plate.

ID PLATE



ETIQUETTE EN 13977




VI - BLADES

SHARPENING :

The shape of the cutting edge along all the blade profile is very important to obtain an optimum cutting quality

The blades must systematically be inspected and sharpened (**about every 50 cuts**)



PROFILE BLADES LIST FOR THE VARIOUS TYPES OF VIGNOLE RAILS


Lengthened Blades 32 type Standard 11335018		Lengthened Blades 36 type Standard 11335019		Lengthened Blades 40 type Standard 11335024		Lengthened Blades 45 type standard 11335022		Lengthened Blades 48 type Standard 11335023	
H.T.	11335032	H.T.	11335033	H.T.	11335034	H.T.	11335028	H.T.	11335035
20 Kg Std.	34 Kg PLMA	31 Kg Australie	48 Kg LP	41 Kg R41	41,2 Kg Type 16	CFF4	45 Kg AL 16A	45 Kg AL 16A	
25 Kg	65 Lb ASCE	70 Lb U.P.	100 Lb HF	SJ 41	45 Kg EB	CFF4 TJD	50 Kg EB	50 Kg EB	
50 Lb NSFB	Ouganda	36 Kg Anglais	50 Kg N	42,1 Kg R14	105 Lb NYC	S54	UIC 54 - U78	CFF6	
50 Lb OBS	Ouganda	36 Kg UST	50 Kg Nelle Zélande	ou R42	R 65	UIC 54 A (A65)	UIC 54 HM	UIC 60	
26 Kg Std.	36 Kg CFF5	75 Lb ASCE	50 Kg U 50	SJ 43	UIC 60 HH	UIC 60 HH	110 Lb CF & I	110 Lb CF & I	
26 Kg renforcé	UNI 36	80 Lb ASCE	UNI 50	R 43	60 Kg EB	60 Kg EB	110 Lb RE	110 Lb RE	
29 Kg	37,8 Kg AL 11/A	Mozambique	91 Lb RR	91 Lb RR	UIC 61	112 LB RE	112 BC & O	112 BC & O	
BS 60 AFB	75 Lb RBS Ouganda	80 Lb BSA	100 Lb PS	45 Kg ED	113 A	122 BC & O	122 BC & O	122 BC & O	
Anglais	39 Kg ARAB	80 Lb BSA	100 Lb RB	45 Kg	122 Lb	122 Lb	122 Lb	122 Lb	
30 Kg Std.	39 Kg PMA	Sierra Leone	52 Kg Metro	Danemark	63 Kg EB	63 Kg EB	63 Kg EB	63 Kg EB	
30 Kg Nord	80 Lb OBS Ouganda	80 Lb CA	U 60	90 RBS	127 Lb	127 Lb	127 Lb	127 Lb	
30 Kg Suisse	40 Kg Nord	80 Lb RBS	U 60 CA	90 Lb ASCE	127 Lb	127 Lb	127 Lb	127 Lb	
31,6 Kg	40 Kg type Am.	41 Kg Australie	U 60	Mozambique	127 Lb	127 Lb	127 Lb	127 Lb	
33,4 Kg Prussien	85 CF & I	85 Lb ASCE	U 60	90 Lb BSA	127 Lb	127 Lb	127 Lb	127 Lb	
36 Kg Portugal	85 ARAA	85 Lb PS	U 60	47 Kg Australie	127 Lb	127 Lb	127 Lb	127 Lb	
36 Kg S13	45 Kg Nord	45 Kg MSA	S 49	S 49	127 Lb	127 Lb	127 Lb	127 Lb	
36 Kg S40 Std.	45 Kg Est	90,20 ARAA Brésil	50 Kg Chine	60 Kg Australie HH	130 Lb PS	130 Lb PS	130 Lb PS	130 Lb PS	
24 a	45,5 EV45	90,30 ARAB	50 Kg Australie	60 Kg Australie	131 Lb RE	131 Lb RE	131 Lb RE	131 Lb RE	
	46 Kg S12	90 Lb GN	SJ 50	62 Kg S52	130 Lb RE	130 Lb RE	130 Lb RE	130 Lb RE	
	U 33 Ame épaisse	90 Lb RA	UIC 50	130 Lb HF	66 Kg Australie	66 Kg Australie	66 Kg Australie	66 Kg Australie	
	U 33 ou S33	90 Lb RB	50 Kg Australie	60 Kg Australie	132 LB HH	132 LB HH	132 LB HH	132 LB HH	
	U 55	90 Lb SF	100 Lb ARAB	60 Kg Australie	132 LB RE	132 LB RE	132 LB RE	132 LB RE	
	10 a	90 Lb CF & I	100 Lb RA	60 Kg Australie	133 LB RE	133 LB RE	133 LB RE	133 LB RE	
		91 Lb Nelle Zélande	100 Lb RE	60 Kg Australie	136 Lb CF & I	136 Lb CF & I	136 Lb CF & I	136 Lb CF & I	
		CFF1	100 Lb ASCE	53 Kg Australie	136 Lb HH	136 Lb HH	136 Lb HH	136 Lb HH	
		CFF1 TJD	100 Lb ARAB	ou 107 Lb Australie	136 Lb RE	136 Lb RE	136 Lb RE	136 Lb RE	
		UNI 46	100 Lb RA	CFF3 (UIC 54E)	A 74	A 74	A 74	A 74	
		47 Kg Australie			UIC 71	UIC 71	UIC 71	UIC 71	
					155 Lb PS	155 Lb PS	155 Lb PS	155 Lb PS	
					155 Lb Penna	155 Lb Penna	155 Lb Penna	155 Lb Penna	

PANDROL

Cote x : 32-36-40-45-48

BLADES FOR SHEARING MACHINE

01/04/2004



VII - TECHNICAL


Designation	Electric integral version
total mass with motorization and without Blades	55 Kg
total mass without motorization and without Blades	58 Kg
Dimensions L x l x h	1200 x 470 x 480 mm
Engine Power	Electric BOSCH – 230V monophase engine 2600 W
Rotating speed	6500 tr/min.
Insulation class	(IP20)
Protection rating	IP20
Acoustic pressure level Lpa	92 dB (A)
Acoustic power level LWA	105 dB (A)
Vibrational acceleration level :	< 2,5 m/s ²
Force	212 KN (21,5 T)
Output	6.5 l/min. at 6500 tr/min.
Hydraulic pressure	250 bars (3560 Psi)
Mineral hydraulic oil	Following DIN 51524 part 3 norm Category HVLP ISO VG32
DO NOT MIX DIFFERENT TYPES OF OIL	

VIII - LISTE DES PIECES DETACHEES

SPARE PARTS LIST

- Version monobloc
Integral unit
- Tête de tranchage
Shearing unit
- Ensemble traverse arrière et partie hydraulique
Back crosspiece suit with hydraulic part

- Circuit hydraulique
Hydraulic fitting




TETE DE TRANCHAGE
SHEARING UNIT

Rep.	Reference	Qté	Désignation	Description
01	32930051	1	Traverse mobile étroite	Narrow moving crosspiece
02			Jeu de couteau (voir liste en annexe)	Blades (refer to the annexed list)
03	32930052	1	Traverse fixe étroite	Narrow fixed crosspiece
04	41304001	4	Pion de centrage Ø 10x30	Centering piece Ø 10x30
05	35910409	2	Poignée de transport	Handle
06	35910408	1	Traverse arrière	Back crosspiece
07	40924001	8	Ecrou Hm M24	Hm M24 nut
08	35910128	4	Crochet à bossage	Hook
09	35910052	4	Poignée de crochet	Hook handle
10	41120002	4	Rondelle W20	Washer W20
11	41020002	2	Vis CHc M20x50	Screw CHc M20x50
12	41020001	2	Vis CHC M20 x 80	CHc M20 x 80 screw
13	41120005	2	Rondelle plate L20 N	L20 N flat washer
14	41108004	12	Rondelle W8	Washer W8
15	41008020	8	Vis HM8 x 20	Screw HM8 x 20
16	41106001	8	Rondelle W6	Washer W6
17	41006012	8	Vis CHC M6 x 90/30	CHc M6 x 90/30 screw
18	40914004	6	Ecrou bas H M14	Nut H M14
19	44201004	2	Joint racleur	Scraper seal
20a	41014002	2	Vis HM14 x 90	HM14 x 90 screw
20b	41014001	4	Vis HM14 x 60	HM14 x 60 screw
21	41301012	4	Goupille élastique 5x30	elastic pin 5x30
22	47401002	4	Poignée caoutchouc	Rubber handle
23	41008033	4	Vis CHc M8 x 20	Screw CHc M8 x 20
24	41016007	2	Vis de butée HM16 x 160	Stop piece screw HM16 x 160
	45301005	4	Bague autolubrifiante	Self lubricating ring
26	47501011	2	Vérin hydraulique allégé	Light hydraulic jack
27	47501003	2	Colonne de vérin	Jack column
	47501016		Pochette de joints de vérin allégé	Gasket kit for light hydraulic jack

ENSEMBLE TRAVERSE ARRIERE ET PARTIE HYDRAULIQUE

BACK CROSSPIECE AND HYDRAULIQUE PART




ENSEMBLE TRAVERSE ARRIERE ET PARTIE HYDRAULIQUE
BACK CROSSPIECE AND HYDRAULIQUE PART

Rep./item	Qté.	Référence	Désignation	Description
80	1	34910124	Support de pompe	Pump support
		21334010	Partie hydraulique	Hydraulic part
81	1	31230054	Lanterne	Pinion
82	1	31230028	Accouplement complet	Complete coupling
84	2	40906002	Ecrou HM6	HM6 nut
86	1	47702004	Distributeur	Distributor
87	2	41006024	Vis HM 6x50	HM 6x50 screw
88	1	47103001	Pompe avec réservoir 2l	Pump with tank 2l
89	2	41010002	Vis H M10x20	H M10x20 screw
90	8	41008033	Vis CHc M8 x 20	CHc M8 x 20 screw
91	10	41108004	Rondelle W8	W8 washer
92	2	41006003	Vis HM 8x16	HM 8x16
93	2	41114001	Rondelle M14N	M14N Washer
95	2	40914004	Ecrou Hm M14	Hm M14 nut
96	2	41014003	Vis H M14x 60	H M14x60 screw
97	2	41110002	Rondelle W10	W10 washer
99	2	41120001	Rondelle M20	M20 washer
100	2	41020002	Vis CHc M20 x 50	CHc M20 x 50 screw
101	2	41120002	Rondelle W20	W20 washer
102	1	41601010	Collier de serrage	Hose clamp
103	1	48402025	Moteur Electrique Pandrol	Pandrol electric engine
104	2	48402027	Batterie 18V	Battery 18V
105	1	31210503	Bague d'adaption	Adapter ring
106	3	41005027	Vis STHC Ø5 x 12	Screw STHC Ø5 x 12


**CIRCUITO HYDRAULIQUE
VERSION MONOBLOC
MOTEUR ELECTRIQUE****HYDRAULIC FITTING
INTEGRAL TYPE
ELECTRIC ENGINE**

Le circuit hydraulique de l'ébavureuse est composé de
The hydraulic fitting of the shearing machine includes

- Une pompe (*a pump*)
- Un distributeur (*a distributor*)
- 1 jeu tubes et composants flexibles et rigides (*1 set of components, flexibles and steel pipes*)
- REP. REP 1-2 : Ref. 47701047
 REP 3-4 : Ref. 21334011



IX- PLAN DE CONTRÔLE SUIVANT EN13977



**FICHE DE CONTROLE
C L I E N T**
**CONTROL CARD
CUSTOMER'S COPY**

EBAVUREUSE HYDRAULIQUE etroite

INTEGRAL UNIT HYDRAULIC RAIL WELD

11334010

N°	Désignation des contrôles <i>Description of controls</i>	Contrôle <i>Checked by</i>
1	Réglage des vis de positionnement en hauteur : <i>Height positioning screws adjustment :</i>	
2	Réglage des vis de guidage	<i>Guide screws adjustment</i>
3	Système de verrouillage : - Ecrou de réglage en hauteur - Débattement des verrous	<i>Locking system</i> <i>Height adjustment nut</i> <i>Clearance of locks</i>
4	Etanchéité des constituants hydrauliques sous mise en pression : <i>Inspection of hydraulic components under pressure :</i> - Raccords - tuyauterie - Vérins	<i>Couplings</i> <i>Piping</i> <i>hydraulic jacks</i>
5	Essai de fonctionnement à pression maximum de 250 bars <i>Operating test at maximum pressure of 250 bar</i>	
6	Aspect général	<i>General aspect</i>
7	Outilage et cale 31910308	<i>Tools and wedge 31910308</i>
8	Notice d'utilisation 42111006	<i>User's manual 42111006</i>
Date de fabrication		<i>Date of manufacturing</i>
Fait à Raismes le		<i>Drawn up in Raismes, the</i>
Nom		<i>Name</i> :
Signature		<i>Signature</i>

Références à rappeler en cas de réclamation
In case of complaint, please quote these references

N° de machine	<i>Machine nbr</i>	
Moteur Type, N°	<i>Engine Type:</i>	<i>N°</i>
Pompe Type, N°	<i>Pump Type</i>	<i>N°</i>



**FICHE DE CONTROLE
C L I E N T**
**CONTROL CARD
CUSTOMER'S COPY**

EBAVUREUSE HYDRAULIQUE etroite

INTEGRAL UNIT HYDRAULIC RAIL WELD

11334010

N°	Désignation des contrôles <i>Description of controls</i>	Contrôle <i>Checked by</i>
1	Réglage des vis de positionnement en hauteur : <i>Height positioning screws adjustment :</i>	
2	Réglage des vis de guidage	<i>Guide screws adjustment</i>
3	Système de verrouillage : - Ecrou de réglage en hauteur - Débattement des verrous	<i>Locking system</i> <i>Height adjustment nut</i> <i>Clearance of locks</i>
4	Etanchéité des constituants hydrauliques sous mise en pression : <i>Inspection of hydraulic components under pressure :</i> - Raccords - tuyauterie - Vérins	<i>Couplings</i> <i>Piping</i> <i>hydraulic jacks</i>
5	Essai de fonctionnement à pression maximum de 250 bars <i>Operating test at maximum pressure of 250 bar</i>	
6	Aspect général	<i>General aspect</i>
7	Outilage et cale 31910308	<i>Tools and wedge 31910308</i>
8	Notice d'utilisation 42111006	<i>User's manual 42111006</i>
Date de fabrication	<i>Date of manufacturing</i>	
Fait à Raismes le	<i>Drawn up in Raismes, the</i>	
Nom	<i>Name</i> :	
Signature	<i>Signature</i>	

Références à rappeler en cas de réclamation
In case of complaint, please quote these references

N° de machine	<i>Machine nbr</i>	
Moteur Type, N°	<i>Engine Type:</i>	<i>N°</i>
Pompe Type, N°	<i>Pump Type</i>	<i>N°</i>



SAV / Commercial

Contacter votre représentant commercial / Contact your local representative

Ou / Or +33 (0) 1 46 88 17 00

Ou / Or Infos.pandrol-fr@pandrol.com

XI - ATTESTATION DE CONFORMITE

CERTIFICATE OF CONFORMITY

Le constructeur soussigné (the undersigned manufacturer)

PANDROL (DIVISION MATERIEL)

Z.I DU BAS PRE

59590 RAISMES



Certifie que le matériel neuf désigné ci-après

(certify that the under described products)

Tête étroite – Type EME1

MACHINE EME1 Type

Avec moteur électrique BOSCH

With BOSCH electric engine

Référence 11334010

Référence 11334010

N° de machine (machine number) :

Est conforme (comply with)

- **A LA CONFORME EUROPEENE NF EN 13977**
(THE EUROPEENE NORM NF EN 13977)
- **AUX DISPOSITIONS REGLEMENTAIRES DEFINIES PAR LA DIRECTIVE 2006/42/CE**
(THE INFORMATIONS STATED IN THE LEGAL DOCUMENTATION OF THE DIRECTIVE 2006/42/CE)
- **Aux prescriptions de l'article R4313-20 (*procedure d'auto certification*)**
(the regulations of R4313-20 article – self certification procedure)
- **M. LISINSKI Aurélien est le détenteur du dossier technique**

Raismes, 05/2019
Bruno JOIRIS
Directeur Industriel

Aurélien LISINSKI
Responsable division matériel et équipement

PANDROL

Find out more at

pandrol.com

Partners in excellence