

# PANDROL



## Compact Shear B-M-VIR

USER MANUAL



Revision 06  
20 September 2023

**11334018**

**Partners in excellence**

# Revision History

Version	Date	Author	Comments
01	01/09/2021	CHA	Original emission
02	14/12/2021	CHA	Minor corrections
03	05/01/2022	CHA	Warranty added
04	08/03/2022	CHA	Add reference
05	10/08/22	CHA	Spare part list updated
06	20/09/2023	CK	Add support for the drill, control level oil, Modification of the pressure

# Contents

1.	Explanation of symbols	4
2.	General safety instructions	5
3.	Description	6
3.1	Safety precautions	6
4.	Operating instructions	7
4.1	Storage	7
4.2	Handling	7
4.3	Drill connection	8
4.4	Mounting of the blades	9
4.5	Setting before operating	9
5.	Operating	14
5.1	Shearing	14
6.	Working area	16
7.	Maintenance	17
8.	Signalisation	18
9.	Blades	19
9.1	Sharpening	19
10.	Technical characteristics	21
11.	Spare part list	22
12.	Warranty and Service	24
12.1	Warranty	24
12.2	Service	24
12.3	Disclaimer	24
12.4	Contact	24
13.	Recycling and Environment	25

# 1. Explanation of symbols



WARNING! The machine can be dangerous.

Careless and incorrect use results in injury to the operator



Read carefully the instructions of the operating manual before using the machine.



WARNING! Be careful to the mobile pieces of the shearing machine so as to avoid any risk of squashing.

## 2. General safety instructions

- Do not operate the tool until you have been thoroughly and properly trained or under the supervision of an instructor.
- Check power source daily to determine if correct flow and pressure are available. Never exceed flows or pressures for the tool being used. Personal injury or damage to the tool can result.
- Verify that the main electricity supply is the same as the one necessary for the machine perfect running.
- Operators must clear the work area of non-essential personnel. Flying debris can cause serious injury.
- The operator must be familiar with all prohibited work areas such as unsafe grades, poor footing areas and overhead hazards.
- Maintain balance and proper footing at all times. Never overreach to the extent that a broken part or sudden movement of the tool can cause you to lose your balance and fall, or cause injury to yourself or someone else.
- When working near electrical conductors, always assume that the conductors are energized, and that hoses and clothing can conduct harmful electricity. Use hoses labelled and certified as non-conductive.
- Never wear loose clothing that can get entangled in the working parts of the tools or be careless with hands, feet or other body parts around the working parts of the tools. Hydraulic tools exert high torque and force and can cause serious injury or death if improperly used.
- The shearing machine is specially designed to cut the metal excess after an aluminothermic weld, don't divert of its primary function.
- The operator must respect the regulations, procedures and particular orders of the Railway operating Network.
- Never use the shearing machine when you are tired or under influence of medicines, alcohol or substances which can alter your sight, dexterity, or appreciation capacity.
- To avoid personal injury or equipment damage, all tool repair, maintenance or service must only be performed by authorized and properly trained personnel.
- Hydraulic pipes and couplings must be correctly inspected before every use. Any defective component must be rejected.
- Do not clean inspect or repair the tool while connected to the power source. Accidental engagement of the tool can cause serious personal injury.
- Oil injection hazard exists with this tool. Oil injection is a condition where hydraulic oil is injected under the skin from pressure in the line. Always wear gloves and repair any leaks immediately. Never carry a tool by the hoses.
- Do not use damaged equipment. Immediately replace any damaged hoses, fittings, or other components showing wire braid, nicks, cuts, damage or abrasions. Failure to do so may result in equipment damage and / or personal injury or death.
- Clean up any oil or fluid spills immediately.
- Follow all directions for use, maintenance, storage and transportation of the drill according to the manufacturer.
- Shearing machine weight is rather high, so three persons are necessary to handle and place it on track under no circumstances the original design and configuration of the shearing machine should be modify.
- Do not operate the tool at excessive fluid temperatures operator discomfort and potential burns can result at high oil temperatures.
- Always wear safety equipment such as oil injection resistant work gloves, safety glasses, safety boots, ear protection and other safety apparel dictated by your supervisor applicable for the job you are doing and the tool you are using.
- 



## 3. Description

The Pandrol Shearing machine is a light and extremely powerful tool, which is powered by a battery whose purpose is to cut the excess metal induced by the aluminothermic welding process.

Its operation is intuitive and efficient thanks to its motorization by a drill, without percussion, with an 18V battery.

Additionally, chuck attachment is simple and allows a quick connection of the drill to the hydraulic system to provide the 12 ton of force required to shear aluminothermic welds.

### WARNING

The Shearing machine is only compatible with the Milwaukee drill provided (without percussion)

### 3.1 Safety precautions

- Always wear safety equipment such as gloves, safety glasses, ear protection, safety shoes, and other required safety equipment.
- Do not wear clothing which may become entangled in the tool.
- Keep hands clear of work area at all time.
- Always keep work area free of tools or any other objects which may impair sound footing.

### CAUTION

Oil injection hazard exists with this tool. Oil injection is a condition where the hydraulic oil is forced under the skin through pressure in the line. Always wear gloves and repair leaks immediately.

- Because of the high field weld temperatures, it is extremely important to check for worn hoses, nicks, cuts, and/or leaks before each shear operation. Hydraulic oil has a flash point of approx. 204°C /400°F. A leak directed into the weld area (1038°C/1900° F) will cause a fire and possible serious injury or death.
- Do not clean or inspect the tool while it is connected to the power source. Accidental engagement of the tool can cause serious injury.
- Always check work area for any trash which may ignite from sparks, weld splatter or slag.
- Always check the work area for smouldering ties or trash before leaving site.
- Never strike hold downs with any object to loosen shear from the rail.
- Follow all drill manufactures instructions on proper use, maintenance, transportation and storage.

## 4. Operating instructions

### 4.1 Storage

The shearing does not require special storage conditions.

However, be sure to:

- Protect the frame from knocks.
- Do not tilt the shearing machine, which could cause hydraulic oil to leak through the oil tank cap.


Oil specifications :

Amoco Rykon MV	Citgo A/W all temp
Sunvis 706	Mobil D.T.E 13
Chevron EP-MV	Texaco 'Rando' HDAZ
HVLP	ISO VG 32


### 4.2 Handling

The machine ready-to-go weighs 45.3 kg

It requires 3 operators for its handling, one on each side of the machine and one at the end.

 The shearing machine should never be moved with the drill mounted on the machine.


**Figure 1: handling**





## 4.3 Drill connection

Figure 2: Drill connection



- Insert the 3/8 "bit (Item E) in the chuck of the Drill.
- Then fit everything into the square footprint of the pump (mark P).

### WARNING

The drill must be equipped with the handle to be used. Refer to the drill manual for assembly

Figure 3: Handle for the drill




Put directly the handle in the support.




## 4.4 Mounting of the blades

- Remove the 4 screws (mark V) intended to hold the blades on the crossbars.
- Place the blades on the pins (Ref G)
- Using two 22mm wrenches, reassemble the screws and tighten them.

**Figure 4: mounting screws**



**Figure 5: mounting pins**



Nota : for the choice of the blades, refer to the table on page 17.

## 4.5 Setting before operating

### 4.5.1 Setting of the drill

#### **WARNING**

The settings of the screwdriver must be observed. These must not be changed under any circumstances. Changing these settings may cause a malfunction.

#### **WARNING**

In drilling mode, the drill may cause the wrist to twist if it is used without the grab handle. Be sure to follow the handle assembly instructions. The drill must be handled with two hands.

## WARNING

The direction of operation of the shearing is changed using the hydraulic distributor. Under no circumstances should the direction of rotation (counterclockwise) of the drill be changed while the machine is in operation.

**Figure 6: Setting of the drill**




### 4.5.2 Setting of the blades

#### Height adjustment


The front and central cross piece are each fitted with a reference C screw.

These screws should be adjusted to create sufficient clearance between the cutting edge of the blade and the rail.

**Figure 7: Position of vertical adjustment screws**



**Figure 8: Vertical adjustment**



**Operating mode :**

- Unlock the locknuts and loosen the 2 screws item C
- Place the adjusting shim of the desired height on the rail.
- Place the shearing machine on the adjusting shim.
- Tighten the screws marked C until they come into contact with the rail.
- Lock the locknuts

To optimize the cut, this adjustment must be carried out systematically after resharpening or replacing the knives.

---


**NOTA :** For welding gap > 25 mm, create a gap of approximately 4 mm between the blades and the rail.

---

**Setting of the stroke of the cylinders**

To prevent damage to the edges of the blades, it is essential to leave a clearance of 1 mm by adjusting the 2 screws marked D serving as adjustment on the cylinders.

**Figure 9: Setting of the stroke of the cylinders**




- Loosen the adjusting nuts (item D) of the cylinder rod and with the cylinder rods fully extended.
- Adjust the desired gap by moving the adjusting nuts on the cylinder rod.
- Tighten the cylinder rod adjusting nuts, run the shearing machine to check the gap size.
- Reinstall and tighten the cylinder rod jam nuts.

### Setting of the hold down rollers

The hold down roller takes up cutting forces and provides cutting quality and safety.

**Figure 10: Setting of the hold down rollers**



#### Operating mode :

With the shearing machine placed on the rail, with the blades adjusted, rotate the lever (mark L) of the hold down roller by 90 ° so that the roller is engaged under the head of the rail, then:

- Using the knurled nut (item E) raise the hook up to contact under the head
- Loosen the nut 1/8 turn to create a slight play

Proceed in the same way for the 3 other hold down rollers.

---

Nota : For welding gap > 25 mm, create a gap of approximately 4 mm between the blades and the rail.

---

## 5. Operating

Before use, check that all the settings described in the previous paragraph have been made and carry out a no-load test.

### 5.1 Shearing

Place the deburrer on the rail before placing the weld to adjust the hold down rollers. Once the hold-down rollers are adjusted, remove the machine from the rail to prepare for the weld. Do not transport the deburrer with the drill mounted.

#### WARNING


Use only the Milwaukee drill supplied with the machine. Failure to use this drill may result in machine malfunction. Never carry the deburrer while the drill is installed, it could come off and potential damage to the drill could result.

#### WARNING

Make sure the drill is fully charged and running counterclockwise before continuing.  
Make sure that all screwdriver settings have been observed.


- When the weld is ready to be cut, position two people, one on each side of the shear. They should carefully place the shear over the weld and lock it into place with the hold down rollers
- Attach the drill to the weld shear for activating the tool, ensure it is in reverse (counterclockwise rotation) only after the weld shear is installed on the rail.
- Move the handle to side that is labelled “shear” to make the cut.

**Figure 11: Changing the direction of operation**



- Press trigger on drill. Do not release while shearing the weld.
- The flow will stop when the cylinder travel is complete. Release drill trigger at this time.
- After shear is complete, move the handle the opposite direction (labelled retract) to retract the shear blades.

**Figure 12: Changing the direction of operation**



- Press drill trigger again. Drill will continue to operate counter clockwise (in reverse).
- Ensure the shear is fully retracted.
- Remove drill from the weld shear.
- To remove shear from the rail, loosen hold downs, position two people, one on each side of the shear, and carefully remove from the rail.
- Follow all drill manufactures instructions on proper use, maintenance, transportation, and storage.



## 6. Working area

The user's working area is represented by a blue perimeter.

**Figure 13: Working area**



The shearing machine should always be positioned so that the user can easily manipulate the distributor inside the track.

## 7. Maintenance

As the blades wear and/or when replacing blades, the clearance gap between blade tips may require adjusting, this can be done by removing the cylinder rod jam nuts at the rear of the shear. Loosen the cylinder rod adjusting nuts and with the cylinder rods completely extended, set the gap at 1/32"/1mm by moving the cylinder rod adjusting nuts. Retighten cylinder rod adjusting nuts, cycle the shear to check gap dimension. Reinstall and tighten cylinder rod jam nuts.

**Tableau 1: Maintenance periodicity**

OBJECT	OPERATION	PERIODICITY		
		Before use	After use	Presence of signs of wear or improper operation
Complete machine	Inspection of the machine			
Hydraulic hoses	Inspection			
	Replacement			
Quick couplings	Lubrication			
Complete machine	Clean the machine using a clean cloth or air to remove dirt			
Locking mechanism	Replacement			

Use hydraulic fluids that comply with HTMA specification 4.1, the hydraulic fluid should have a viscosity between 100 and 400 ssu (20-82 centistokes) at the maximum and minimum expected operating temperatures. Petroleum based hydraulic fluids with anti-wear properties and a viscosity index of over 140 work for a wide range of operating conditions.

Check regularly the level of oil in the motor pump.

Amoco Rykon MV	Citgo A/W all temp
Sunvis 706	Mobil D.T.E 13
Chevron EP-MV	Texaco 'Rando' HDAZ
HVLP	ISO VG 32

Other fluids that meet or exceed this specification can be used. \*See cold weather operation hydraulic oil note.

Have tool inspected, at least annually, by Pandrol or a Pandrol qualified service representative to determine if tool is in need of safety changes or worn part replacement.

- Contact pandrol on a periodic basis, at least annually, for service bulletins, safety notices, or other important information pertaining to this tool.
- Follow all drill manufactures instructions on proper use, maintenance, transportation, and storage.

## 8. Signalisation

Our deburring machines benefit from traceability included on this company nameplate.

Figure 14: Company nameplate


Model : Compact-Shear B-M-VIR		<b>PANDROL</b> <small>Partners in excellence</small>	<b>E+</b>
Item n° : 11334017	Serial n° :		
Weight : 40 kg	Norm : EN 13977	25 Interstate Drive Napoleon, OH 43545 <a href="http://www.pandrol.com/contact">www.pandrol.com/contact</a> <a href="http://www.pandrol.com">www.pandrol.com</a>	 Made in the USA
Flow : 19 L/min	W. Press : Bar		
Manuf. Date :	SNCF N°:		

Figure 15: sticker EN 13977



## 9. Blades

### 9.1 Sharpening

The geometry of the cutting edge over the entire profile of the blade is very important to obtain the optimum quality of shearing.

Blades must be systematically monitored and resharpened (approximately every 50 cuts)

**Figure 16: Sharpening of the blades**







Figure 17: Types of blades to use according to the rail profiles


TYPES DE COUTEAUX A UTILISER SELON LES PROFILS DE RAILS					
Type 32 Rallongés Standard 11335018 H.T. 11335032	Type 36 Rallongés Standard 11335019 H.T. 11335033	Type 40 Rallongés Standard 11335024 H.T. 11335034	Type 45 Rallongés Standard 11335022 H.T. 11335028	Type 48 Rallongés Standard 11335023 H.T. 11335035	
20 Kg Std. 25 Kg 50 Lb NSFB Ouganda 50 Lb OBS Ouganda 26 Kg Std. 26 Kg renforcé 29 Kg BS 60 AFB Anglais 30 Kg Std. 30 Kg Nord 30 Kg Suisse 31,6 Kg 33,4 Kg Prussien 36 Kg Portugal 36 Kg S13 36 Kg S40 Std. 24 a	34 Kg PLMA 65 Lb ASCE 70 Lb ASCE Thaïlande 36 Kg UST 36 Kg UST Suisse 36 Kg CFF5 UNI 36 37,8 Kg AL 11A 75 Lb RBS Ouganda 39 Kg ARAB 39 Kg PMA 40 Kg Nord 40 Kg type Am. 85 CF & I 85 ARAA 45 Kg Nord 45 Kg Est 45,5 EV45 46 Kg S12 U 33 Ame épaisse U 33 ou S33 U 55 10 a	31 Kg Australie 70 Lb U.P 36 Kg Anglais 37,2 Kg Anglais 75 Lb ASCE 80 Lb ASCE Mozambique 80 Lb BSA 80 Lb BSA Sierra Leone 80 Lb OBS Ouganda 80 Lb RBS 41 Kg Australie 85 Lb ASCE 85 Lb PS 45 Kg MSA 90,20 ARAA Brésil 90,30 ARAB 90 Lb GN 90 Lb RA 90 Lb RB 90 Lb SF 90 Lb CF & I 91 Lb Nlle. Zélande CFF1 CFF1 TJD UNI 46 47 Kg Australie	41 Kg R41 SJ 41 42,1 Kg R14 ou R42 SJ 43 R 43 91 Lb RR 45 Kg ED 45 Kg Denmark 90 RBS 90 Lb ASCE Mozambique 90 Lb BSA 47 Kg Australie S 49 50 Kg Chine 50 Kg Australie SJ 50 UIC 50 100 Lb AREA 100 Lb ASCE 100 Lb ARAB 100 Lb RA 100 Lb RE 100 Lb CF & I 53 Kg Australie ou 107 Lb Australie CFF3 (UIC 54E)	41,2 Kg Type 16 45 Kg AL 16A 50 Kg EB 105 Lb NYC CFF6 R 65 UIC 60 UIC 60 HH 60 Kg EB UIC 61 122 BC & O 122 Lb 63 Kg EB 127 Lb 127 Lb NYC 130 Lb PS 131 Lb RE 130 Lb RE 66 Kg Australie 132 Lb HH 132 Lb RE 133 Lb RE 68 Kg Australie 136 Lb CF & I 136 Lb HH 136 Lb RE 140 Lb RE A 74 UIC 71 155 Lb PS 155 Lb Perna	CFF4 CFF4 TJD S54 UIC 54 - U78 UIC 54 A (A65) UIC 54 HM 110 Lb CF & I 110 Lb RE 112 Lb RE 113 A 113 Lb HF 115 Lb RE 119 Lb CF & I 60 Kg Australie HH 60 Kg Australie 119 Lb 62 Kg S52 130 Lb HF
					<b>RAILTECH</b> INTERNATIONAL © BREVET DÉPOSÉ
Cote x : 32-36-40-45-48					COUTEAUX DE TRANCHEUSE 01/04/2004

# 10. Technical characteristics

Figure 18: Illustration



Figure 19: Technical characteristics



Flow	Pressure	Dimensions	Weight w/o drill
5 GPM (19 LPM)	190 BAR	A- 30.5" (775 mm)	98 lbs (45.3 kg)
		B- 27.75" (705 mm)	
		C- 27.75" (705 mm)	

# 11. Spare part list


ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	47703009	3/8 NPT x -06 JIC 45 ELBOW	2
2	47703010	3/8 NPT STREET 90 ELBOW	2
3	47702060	DETENT VALVE KIT	1
4	47702061	HYDRAULIC CYLINDER	2
5	47703007	3/8 JIC x 3/8 NPT 90 ELBOW	2
6	47703008	3/8 JIC x 3/8 JIC x 3/8 NPT TEE	2
7	48601578	FRONT HOLD DOWN HANDLE	2
8	48601579	CENTER HOLD DOWN HANDLE	2
9	48601580	FRONT ROLLER ASSEMBLY	2
10	48601581	CENTER ROLLER ASSEMBLY	2
11	47601013	HOSE	2
12	48607001	SPIDER COUPLING HOUSING	1
13	48607002	PUMP SPLINE ADAPTER	1
14	48607003	3-928 O-RING	1
15	47103017	KP25 PUMP/RESERVOIR	1
16	44302005	SPIDER COUPLING HUB	2
17	44302006	SPIDER COUPLING FLEXIBLE HUB	1
18	48601582	CENTER PLATE	1
19	48601583	FRAME	1
20	47601014	HOSE	2
21	47601015	HOSE	2
22	41108011	VALVE SPACER	4
23	45301004	OILITE BRONZE BUSHING	1
24	48607004	SHAFT SEAL	1
25	48607005	DRILL COUPLER ADAPTER	1
26	48607006	CAP	1
27	41120006	TOOTH LOCKWASHER	4

THE FOLLOWING COMPONENTS NOT SHOWN  
- MILWAUKEE #48-32-5031 1/4" HEX X 3/8" SQ SOCKET ADAPTER  
- MILWAUKEE #2803-20 M18 FUEL 1/2" DRILL DRIVER (TOOL ONLY)

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
28	41402001	3/16" SQ. X 3/4" STEEL KEY	2
29	48612018	RESERVOIR BREATHER CAP	1
30	47703011	-06 JIC x -04 O-RING	2
31	47703012	-06 JIC X -04 O-RING 90 ELBOW	2
32	40919001	3/4-10 PLAIN HEAVY HEX NUT	4
33	40919002	3/4-16 PLAIN HEAVY HEX NUT	2
34	40919003	3/4-16 HEX JAM NUT	4
35	41112005	1/4 LOCK WASHER	4
36	41109001	3/8 LOCK WASHER	2
37	41303005	DIA. 3/16 x 1 SPRING PIN	4
38	41008071	5/16-18 x 1 3/4 FLAT HEAD SCREW	4
39	41006064	1/4-20 X 5/8 BHCS	4
40	41009001	3/8 X 3/4 BHCS	2
41		BLADE ADJUSTMENT SCREW	2
42		M14 x 30mm Hex Head Cap Screw	4
43		Dowel Pin	4

SHEET 1 OF 2





SHEET 2 OF 2

# 12. Warranty and Service

## 12.1 Warranty

All products from Pandrol are supplied with a 12-month Warranty.

The Warranty is not valid if the indicated defect or fault in the product does not exist or if the fault is the result of a handling error, tampering or non-permitted modification, or if the machine has been exposed to fire, lightning or excess voltage.

## 12.2 Service

Aftersales support and technical service are available from Pandrol, during and after the Warranty period. Please contact Pandrol.

## 12.3 Disclaimer

Pandrol exempts itself from liability in the event of usage that deviates from that recommended in this manual.

## 12.4 Contact

**Table 1: Contact**

Address	Phone	Internet and E-mail
Pandrol Z.I Rue du Bas Pré, 59590 Raismes, FRANCE	+33 (0) 6 45 67 97 19	<a href="http://www.pandrol.com">www.pandrol.com</a> <a href="mailto:contact.sav@pandrol.com">contact.sav@pandrol.com</a>

# 13. Recycling and Environment

Sustainable environment is a great part of Pandrol.

All components of the Power unit can either be:

- Recycled
- Taken care of
- Be re-used



We recommend you to follow your local region regulations of environmental and recycling policies

# PANDROL

Find out more at  
[pandrol.com](https://pandrol.com)

© Pandrol

Partners in excellence