

# PANDROL



## User Manual

OBSTRUCTIONLESS JACK



Revision 01

**Partners in excellence**



# Revision History

Version	Date	Author	Comments
01	29-05-20	C.CHA	Original emission

# Contents

<b>1.</b>	<b>Explanation of symbols</b>	<b>4</b>
1.1	Security's pictograms	4
1.2	Unified symbols on the machine	6
1.3	Responsibility	6
<b>2.</b>	<b>General safety instructions</b>	<b>7</b>
2.1	General warning	7
2.2	Environmental conditions	8
2.3	Prohibited uses	8
2.4	Allowed uses	8
2.5	Care and maintenance	9
2.6	Residual risk	9
2.7	Required operator's training	9
2.8	Expected use	9
2.9	Not expected use	10
2.10	Safety work	10
<b>3.</b>	<b>Presentation</b>	<b>11</b>
3.1	General	11
<b>4.</b>	<b>Use</b>	<b>12</b>
4.1	Transport and movement	12
4.2	Put to use	12
4.3	Protection and storing	13
4.4	Machine removal away from rails	13
<b>5.</b>	<b>Machine use</b>	<b>14</b>
5.1	How to use the machine	14
<b>6.</b>	<b>Maintenance</b>	<b>15</b>
6.1	Preface	15
6.2	Fire	15
6.3	Breaking up and disposal	16
<b>7.</b>	<b>Spare parts</b>	<b>17</b>

# 1. Explanation of symbols



**DANGER**

it refers to dangers dealing with the described activity. When there is “DANGER” we refer to activities that could occur while using the machine and could endanger people.



**ATTENTION**

it refers to dangers dealing with the described activity. When there is “ATTENTION” we refer to activities that could occur while using the machine and could endanger the machine.








**WARNING**





We refer to integrations or suggestions for a correct use of the machine and to illustrate basic characteristics.

## 1.1 Security’s pictograms

Pictograms inside a triangle indicate DANGER.

Pictograms inside a circle impose a PROHIBITION/OBLIGATION.


Pictograms	Description
	Danger electric tension.
	Arms crushing.
	Hitching on.
	Dragging.
	Generic danger.

Pictograms	Description
	<p>No entry for not authorized personnel.</p>
	<p>Don't remove security devices.</p>
	<p>Don't clean, oil, grease, repair or adjust working parts by hand.</p>
	<p>Don't execute works before remove tension.</p>
	<p>Obligatory protection gloves.</p>
	<p>Obligatory safety footwear.</p>
	<p>Obligatory safety helmet.</p>

## 1.2 Unified symbols on the machine


Unified symbols that follows indicate danger operation or situations that could occur while using the machine.

**ATTENTION**



If the decals (illustrated above) are not legible, you have to substitute them with new ones.

**Table 1: Unified symbols and meanings**

Meaning	Symbol
This symbol indicates that you have to consult the manual.	

## 1.3 Responsibility


Pandrol is dispensed from any responsibility and obligations about any kind of accident to people and things, that could occur for:

- Failed observance of the instructions written in this manual concerning the condition, the transport, the use and the maintenance of the machine
- Violent actions or incorrect maneuvers during the transport, use and maintenance of the machine
- Any modifications to the machine made without PANDROL authorization
- Events that does not deal with the normal and correct use of the machine

Anyway, if the user would attribute the accident to a machine’s fault, would have to demonstrate that the occurred damage was a main and direct consequence of this “fault”.

The responsibility of the formation, education, training and retraining of the personnel that uses the machine described in this manual, is exclusively dependent on owner/user of the machine.

**ATTENTION**



For the maintenance and repairs you have to use only original spare parts. Pandrol declines all the responsibility for damages that could occur for non-fulfilment for what said before.

The machine is guaranteed according to contract stipulated during the sales. Warranty is null if rules and instructions written in this manual haven’t been obeyed.

## 2. General safety instructions

### 2.1 General warning

- The operator and all the personnel that interact with the machine must be equipped of specific individual protection's devices (DPI).
- Machine's placement and use are reserved only for in charge personnel.
- Never use the instrument when its poor condition is evident. Remove all the instruments that has visible deformations. Constantly check the instrument's status.
- Do not use the machine to lift people.
- Avoid overloading and check that the load never exceeds the rated capacity stated on the label if the application is made on the head and 70% of that value if the application is done on foot.
- Do not use shims between the head or the arm of the machine and the load to be lifted
- Always check that the load is centered.
- The load to be lifted must be guided laterally, so that the foot of the jack, in operation, cannot rotate about the axis during the climb.
- For use on the foot is necessary that at least 3 teeth of the foot are in contact with the load.
- Never work under a lifted load.
- Do not bump the load being lifted.
- Do not lift loads that can deform or having parts not securely fastened to each other.
- Never leave the lifted load unattended.
- Before starting the manoeuvres, you have to assure that in the sphere of activity of the machine there aren't people. If you need, signal the start of the operation.
- During the lifting operations remain outside the zone of action of the machine to avoid being affected by a possible fall of the load.
- Lift the machine carefully avoiding the use of the control lever.
- Adequately light the working area.

#### ATTENTION



It is impossible to list all the possible safety rules, so we entrust operator good sense, who, if he works with care and caution, guarantees the best safety against every kind of accident.

## 2.2 Environmental conditions

The machine in standard configuration is designed to be used in these environmental conditions:

- Work temperature: + 25°C
- Max temperature: + 40°C
- Min temperature: - 20°C
- Relative damp: 20% - 80% (without moisture)

The machine in standard configuration must work only in these environmental conditions

### ATTENTION



It is forbidden the use of the machine in standard execution in areas that are different from the listed above. The eventual use of the machine in non-suitable places can cause the malfunctioning or the breaking of the machine's hydraulic components.

## 2.3 Prohibited uses

- Use the machine for aims that are different from those it is designed for
- Not correctly or moved and started according to its safety/service rules
- Carelessness and/or absence of maintenance as prescribed or use of non-original spare parts
- Use of the machine out of allowable environmental conditions
- Use the machine with excluded or damaged safety devices
- Use the machine modified in any of its parts without a written PANDROL authorization
- Use of the machine on rails without respect the rules of the railway body owner of the railway
- Use of the machine on rails open to traffic
- Use of the machine on track circuit
- Use the machine in presence of a third rails
- Use the machine in presence of inclination superior or equal to 40%
- Go away from the machine leaving the engine running
- Not under the influence of drugs or alcohol.

## 2.4 Allowed uses

- Use the machine built only with the compatible equipment, in specific working conditions.
- Use the machine only on non-open traffic rails.



## 2.5 Care and maintenance

To execute maintenance and repairs, you have to move the machine in a place authorized by the team leader of the yard.

To maintain the machine clean, never use liquids easy flammable and corrosive products.

For the maintenance it is necessary the use of suitable tools

### ATTENTION



It is impossible to list all the possible safety rules, so we entrust operator good sense, who, with care and caution, guarantees the best safety against every kind of accident.

## 2.6 Residual risk

Dangers that could not be deleted from safety measures adopted by the manufacturer couldn't be caused by an incorrect use of the machine or by a failed respect, due to the user, of the rules described in this manual.

The personnel in charge of the machine must be equipped of specific individual protection's devices required by law.

### ATTENTION



During every kind of work pay attention of high voltage line, if you are next to them could cause DEATH.

## 2.7 Required operator's training

Every operator must read entirely with full attention this manual and respect what is written.

The Employer is obliged to verify that the operator owns all the abilities required for the operation of the machine and has carefully reviewed the manual and has to give to machine's user devices for personal protection (gloves, shoes, clothes, etc.) according to rules in force.

## 2.8 Expected use

The machine has been designed and manufactured by Pandrol to execute lifting operations.

There must be carefully respected safety prescriptions passed from Railway Administrations for works on rails and near them. You must start working only after the officials in charge for safety have given their go ahead.

You have quickly and carefully executed the guidelines conveyed by the Site Manager or the safety responsible. Always leave devices and material in a way that these ones cannot collide with other railway vehicles. In case of use in the presence of the third rail, it is essential to make sure that the third rail is isolated otherwise do not work.

## 2.9 Not expected use



Not observe the prescribed limits is equivalent to an improper use of the machine. If this happens, PANDROL will not assume any liability for accidents to persons or damage to property or the machine itself.

## 2.10 Safety work

Pandrol does not answer for accidents, working's anomalies and/or damages during the machine's use, due to user's nonobservance of laws, prescriptions, dispositions, and rules in force.

The use of the machine is allowed only at the trained personnel. Only authorized people can stay near the machine. You have always to stay by safety distances from mobile parts and check that during its work normal safety prescriptions are respected. You always must assure that advertisement given to other people are understand and executed.


Dangers that could not be deleted from safety measures adopted by the constructor couldn't be caused by an incorrect use of the machine or by a failed respect, due to the user, of the rules described in this manual.

# 3. Presentation

## 3.1 General

The machine has been realized specially for levelling and tamping works of rails. Made with high quality materials, it guarantees high performances in any working conditions, extraordinary use simplicity and maximum safety for the operator. It has lever and spring of rapid release on the superior part of the structure and of a screw for height adjustment with squared nipple 22 UNI.

Figure 1: Positioning of the machine



- 1. Base
- 2. Grip on rails
- 3. Worm
- 4. Seat for T-wrench
- 5. Lever
- 6. Handle

Table 2: <Insert Table Title here>

Technical data	
Lifting capacity	10 000 daN – 10 t
Pace	7 mm
Run	180 mm
Total dimension	500 x 200 mm
Dimension of the foot	300 x 200 mm
Height	500 mm
Weight	19 kg

## 4. Use

### 4.1 Transport and movement

The lifting of the components of machine can be done only by using highlighted devices' grips that are on the machine.

#### ATTENTION



We recommend using expected personal safety devices as: gloves, safety footwear with steel toe and overalls.

#### DANGER



Bump and crushing danger. During the lifting and moving you have to operate carefully.

### 4.2 Put to use

#### 4.2.1 First start up

At the first start of the machine you must execute checks that follow:

1. Verify that the machine has:
  - a. Declaration of conformity CE
  - b. Operation and Maintenance manual
2. General visual check of the machine
3. Check and verification of the presence of identification's plate and of safety labels
4. Varnishing's check
5. Running test-load operation, making sure that the lever moves without too much effort
6. After the necessary tests to check if there are losses.

#### ATTENTION



Before starting the machine, the operator in charge must read completely this manual

## 4.2.2 Checks at the beginning of every working day

Before the start of every working day you must check:

1. General visual check of the machine
2. Check and verify the presence of identification's plate and of safety labels
3. Varnishing's check

If one or more described points are damaged, do not use the machine and provide for re-establish the machine in efficiency conditions.

If there are any anomalies that the operator could not solve, contact PANDROL.

## 4.3 Protection and storing

1. Put the machine in a way that can guarantee the adequate safety

### 4.3.1 Reclamation after a long inactivity

1. Carefully clean the machine

## 4.4 Machine removal away from rails

Removal operation of the machine from rails must be done this way:

1. Release the spring lever located at the back so as to rest the load;
2. Remove the machine away from the rail and store it in a safe place.

The necessary time to do the machine's removal maneuver from rails is 10 seconds, in normal operative conditions. The number of necessary operators for machine's removal from rails is 1.

### ATTENTION



We recommend using expected personal safety device as: gloves, safety footwear with steel toe and overalls.

## 5. Machine use

### 5.1 How to use the machine

1. Verify that the support plane and the working areas are solid enough to operate
2. Place the equipment with care and precision under the rail to lift
3. Rising phase: spin the T-wrench clockwise.
4. For the fall phase: spin the T-wrench counterclockwise.
5. Rising and fall operation could be interrupted in any position.

#### DANGER



We recommend using expected personal safety devices as: gloves, safety footwear with steel tip and overalls.

#### ATTENTION



Bump and crushing danger. During the lifting and moving you must operate carefully

#### ATTENTION



It is forbidden to load the equipment with material that overcome the allowed maximum weight. Pay attention that the weight of the material is balanced on the equipment and uniformly divided on the axis to avoid its fall during the working phases. Assure that the ground is solid enough.

#### DANGER




Once you've inserted in its seat the T-wrench, check if it regularly idles without hitches

# 6. Maintenance

## 6.1 Preface

**ATTENTION**



Maintenance operations must be executed only by PANDROL Customer Service or by qualified personnel

In order to obtain best performances and to assure all the elements the maximum life, is necessary that use and maintenance's rules are carefully followed by the operators in charge. For this we suggest to Customers, in their interest, to carefully read these notes and to consult the manual every time they need suggestions to avoid eventual drawbacks. As the machine normally works closet o water, sand, ground, etc, a rational lubrication is necessary, that assumes a vital importance for the long use of the machine and to contain its exercise's cost.

For further clarifications call up our customer care:

- Ordinary maintenance includes all the necessary information for the good functioning and preservation of the machine.
- We suggest letting the same operator do maintenance operations, he is familiar with the machine, how it works and must know what is in the manual.
- During the disassembling and re-assembling you always must use the extractor, keys, and suitable equipment to avoid deteriorate parts.
- To unlock sized parts, use copper's hammer or wooden mallet.
- Clearly separate elements of various groups and screw back the nut in part on its pins or studs. Clean the parts with rag, and then clean with de-grease blowing off residuals with compressed air.
- During the re-assembling of various parts, assure that they are clean and then carefully lubricate.
- Pay the maximum attention on safety rings and to the cotter pins: if they have damages traces immediately substitute them.

Ordinary maintenance's operations indicated on the table that follows must have the same frequency of the machine's working hours indicated on the column at the right, under "PERIOD".

**Table 3: Maintenance table**

Number	Operation	Period
1	Check if there are deformations or brakes	Before every use
2	Greasing of contact and sliding parts	40 hours

## 6.2 Fire

In case of start of a fire, use a CO2 extinguisher (not supplied) according to guidelines in force.

In case of machine's fire or if the machine is near a fire, give the alarm in the yard and call up the firemen.



### 6.3 Breaking up and disposal


At the end of machine's life, remember that the owner of the mean must provide for the breaking up and for the machine's disposal according to guidelines in force and throughout authorized disposer for each component of the machine.

Remember that every time that you substitute oil, hose, and every machine's detail prone to different disposal, you always need to make reference to rules in force and to authorized disposals



# 7. Spare parts

Figure 2: Exploded view



Item	Qty	Description
1	1	Support foot
2	1	Lifting support
3	1	Screw locking
4	2	Nut
5	1	Crescent
6	1	Lifting screw
7	1	Fast release
8	1	Long pin
9	1	Quick release
10	2	Spring pin
11	1	Pin
12	1	Spring

# PANDROL

Find out more at  
[pandrol.com](https://pandrol.com)

© Pandrol

Partners in excellence

